

## **YGE ProgCard II - Programming Board**

### **Quick Guide for Opto regulator V4**

#### **Programming:**

- Pull the long controller cable from the receiver.
- Put the short controller cable on the left connector (esc) of the ProgCard with orange to the left.
- Insert the patch cable to the right connector (Tx) of the ProgCard, with orange to the left.
- Plug the other end of the patch cable into the throttle channel of the receiver.
- Turn on transmitter. (On Futaba activate servo reverse on the gas channel.)
- Turn on the receiver.
- Connect the main battery.
- On the ProgCard press Enter.
- Controller will then read out and can be programmed.
- After programming, disconnect the main battery, remove the ProgCard and patch cables.

#### **Operation:**

- Insert the long cable from the controller into the throttle channel of the receiver.
- Turn on transmitter.
- Turn on the receiver.
- Connect the main battery.